

Toner Product List

FOR USE IN HP				
Item	Product No.	Cartridge Code	Machine Models	Remark
1	HJ-301H	C4092A	HP 1100/1100A/3200	2612 series Classic HP universal toner
		C7115A/X	HP 1000/1005/1200/1220/3300/3310/3320/3330/3380	
		CF280A/X	HP PM401D/M401DN/MFP 425DN	
		Q2612A/X	HP 1010/1012/1015/1018/1020/1022/M1005/M1319F	
		Q2613A/X	HP 1300/1300N/1300XI	
		Q2624A/X	HP 1150/1150N	
		Q3906A	HP 5L/6L/3100/3150	
		Q5949A/X	HP 1160/1320	
		Q7553A/X	HP P2015/P2015D/P2015DN	
		CF226A/X	HP M402/M406	
		CF228A/X	HP M403/MFP M427	
		CE505A/X	HP P2030/2035/2055	
2	HJ-302H	CF283A/X	HP M125NW/M125/M126FN/M127FN/M127W/M128fn/M128fp/M128fw /M225/M201dw/M201n/M226dn/M226dw	Classic HP Universal toner, with high blackness and not pollute PCR
		CE285A	HP P1102/1102W/1132/1212	
		CE278A	HP M1536dnf/P1566/P1606dn	
		CB388A	HP P1007/P1008/M1132/M1136/M1212nf/M1213nf/M1214nfh /M1216nfh/M1217nfw/M202dw/M202n/M226dn/M226dw/P1106/P1106W/P1108	
		CB435A	HP P1002/P1003/P1004/P1005/P1006/P1009	
		CB436A	HP P1500/1505/1522/M1120/1120N/1522N	
		C4092A	HP 1100/1100A/3200	
		C7115A/X	HP 1000/1005/1200/1220/3300/3310/3320/3330/3380	
		CF280A/X	HP PM401D/M401DN/MFP 425DN	
		Q2612A/X	HP 1010/1012/1015/1018/1020/1022/M1005/M1319F	
		Q2613A/X	HP 1300/1300N/1300XI	
		Q2624A/X	HP 1150/1150N	
		Q3906A	HP 5L/6L/3100/3150	
		Q5949A/X	HP 1160/1320	
		Q7553A/X	HP P2015/P2015D/P2015DN	
		CF226A/X	HP M402/M406	
		CF228A/X	HP M403/MFP M427	
		CE505A/X	HP P2030/2035/2055	
3	HJ-401H	CE390A/X	HP M600/M601n/M601dn/M602n/M602dn/M602x/M603n/M603dn/M4555/M4555f/M4555fxkm/M4555h	Universal toner for HP medium and high-speed machine
		CE255A/X	HP P3010/P3015/P3015d/P3015dn/P3015n/P3015x/P3016/M521dn/M521dw/M525c/M525dn/M525f	
		Q7516A	HP 5200/5200TN/5200DTN/5200L/5200LX	
		Q7551A/X	HP P3005/M3027/x/M3035/xs	
		Q5942A/X	HP 4200/4250/4350/4345	
		CE364A/X	HP P4014/4015/4515	
		C8061A/X	HP 4100	
		Q4129X	HP 5000/5100	
		C4127A/X	HP 4000/4050	
		Q1338A	HP 4200	
		Q1339A	HP 4300	
		Q4182X	HP 8100/8150	
		CF214A/X	HP 700/M712/M725	
		CF325X	HP M806X/M806DN/M830Z	
		CF237A/X	HP M607/608/609	
4	HJ-901H	CF258/276/277	HP M404/M405	277 series universal toner
		CF289A/X	HP M507/M528	
		CF1370	HP M208/M233	
		CF1470	HP M610/611/612	
		CF1480/1490/1520	HP 4001/4002/4004	

Item	Product No.	Cartridge Code	Machine Models	Remark
FOR USE IN SAMSUNG				
Item	Product No.	Cartridge Code	Machine Models	Remark
5	HJ-S01	ML-1210D3	SAMSUNG ML-1010/1020M/1210/1220M/1250/1430	Classic Samsung Universal toner It cannot be used in ML101/111
		ML-1610D2	SAMSUNG ML-1610/2010/SCX4521	
		ML-1630A	SAMSUNG ML-1630/SCX4500	
		ML-1710D3	SAMSUNG ML1710/1510/1520/1740/SCX4016/4216F/SF560/565P	
		ML-2010D3	SAMSUNG ML2010/2510/2570/2571N/SCX4521	
		ML-D103S	SAMSUNG ML-2956ND/2951D/2956DW ; SCX4729HD/4728HN	
		ML-D1043S	SAMSUNG ML 1660/1665/1665K/1661K/1861/1865/1678/SCX3206W	
		ML-D1053L	SAMSUNG ML-1910/2525/2580N ; SCX4600/4623FN ; SF-650	
		ML-D108S	SAMSUNG ML1640/1641/2240/2241	
		ML-D109S	SAMSUNG SCX4300	
		ML--D209L	SAMSUNG ML 2855ND/SCX4824FN/4826FN/4828FN	
		ML-D2250B	SAMSUNG ML 2250/2251N/2251NP/2251W/2252/2252W	
		ML-D2850B	SAMSUNG ML 2850/2850D/2851ND	
		SCX-4100D3	SAMSUNG SCX-4100	
		SCX-4521D3	SAMSUNG SCX-4321/4521F	
		ML-4500D3	SAMSUNG ML-4500/4600	
		ML-5100D3	SAMSUNG SF-5100/5100P/515/530/550/ML808	
FOR USE IN Pantum				
Item	Product No.	Cartridge Code	Machine Models	Remark
6	HJ-B01	DL-400/411/413	Pantum M6700/P3010/M7100/P3305/M7115	
FOR USE IN CANON				
Item	Product No.	Cartridge Code	Machine Models	Remark
7	HJ-302H	CRG 137/337/737	Canon imageClass MF210/MF211/MF220;Satera MF210/MF211/MF220;	
		CRG 125/325/725/925	Canon i-SENSYS LBP6000/Lasershot LBP6018; ImageClass MF3010/LBP 6030b/6030w;	
		CRG 128/328/728/928/326	Canon i-SENSYS LBP6200/6200D; FAX-L170 Canon ImageClass MF4410/MF4412/4420/4430/4450/4550/4550D/4452/4570dn/4580dn/4720w/4750/4820d/4870dn/4890dw/	
		CRG 312/712/912	Canon i-SENSYS LBP 3050/3150/3010/3100/3018/3108;	
		CRG 313/713	Canon LBP 3250;	
		CRG 119/319/519/719	Canon i-SENSYS LBP6300dn/LBP6650dn/MF5850dn/MF5880dn/MF5950dw/MF5960dn ; ImageClass LBP 6680X ;LBP6670dn/MF6180dw;	
		CRG FX9/103/303/703	Canon FAXPHONE L90/L100/L120/L140/L160/ImageClass D420/D480/D480 Refurbished/MF4010/MF4012/MF4100/MF4110/MF4120/MF4122/MF4140/MF4150/MF4270/MF4320d/MF4330d/MF4340d/MF4350d/MF4350d Refurbished/MF4370dn/MF4370dn/MF4380dn;	
		CRG 115/315/515/715/915	Canon LBP 3310/3370;	
		CRG 108/308/508/708/908	Canon LBP3300/3360;	
		C-EXV40A/X	Canon IR 1133/1133A/1133iF;	
		NPG-18	Canon IR2200/2220N/2220I/2800/3300/3320N/3320I	
		NPG-20	Canon IR155/165/200/1600/2000/2010/2016/2018/2020/2022/2025/2030	
		NPG-59	Canon IR2002L 2002G 2202N 2202L	
		NPG-51	Canon IR2520/2525/2530/2535/2545	

Item	Product No.	Cartridge Code	Machine Models	Remark
8	HJ-401H	EP CRG U	Canon LBP 3200/MF 3110/MF 5630/5650/1800/1840/3210	
		EP CRG T.W.FX-8.S35	Canon fax L400/Image Class D320/D323/383/L398/390/ HP	
		EP CRG N	Canon PC1210/1230/1250/1270/D620/D660/D680	
		X25	Canon Image Class MF3110/MF3111/MF3240/MF5530/MF5550	
		CRG 106/306/706	Canon image Class MF6350/MF6540/MF6550/MF6560/MF6580/MF6590/	
		CRG 308/508/708	Canon LBP 3360/3300	
		CRG 109/309/709	Canon LBP 3500/3900/3950	
		CRG 310/710	Canon LBP 3410/3460	
		CRG 319/319II/519/719	Canon LBP 6300/6300DN/6650/6650DN/MF5850DN/5840/5488	
		CRG 324/524/724	Canon LBP 6750/6750DN	
		EP-22	Canon LBP 200/250/350/800/810/1110/1120	
		CRG 333	Canon LBP8750n/8780x;	
		EP-26/27	Canon LBP 3200/MF3110/MF5630/5650/1800/1840/2140/3210	
FOR USE IN RICOH				
Item	Product No.	Machine Models		Remark
9	HJ-C12	Ricoh Aficio MP1060/2051/2075/5500/6000/6001/6002/6500/7000/7001/7500/7502/8000/8001/9001/9002/SP9100DN		
		Ricoh Aficio 1085/1105/2090/2105		
		Ricoh Aficio MP1100/1350/9000/PRO 1107/1157/906/907		
		Ricoh Aficio MP1350/9000		
		Ricoh Aficio MP1350/ Pro1357 EX		
FOR USE IN XEROX				
Item	Product No.	Machine Models		Remark
10	HJ-C16	Xerox AP3501/4501/5501/II3000/4000/5010/DCII 4000/5010		
		Xerox WC5875/5855/5890		
		Xerox DCIV 2060/3060/3065/5775/5855		
		Xerox wc5225/5230/5222		
		Xerox DC 236/286/186/156/123/128		
		Xerox 4110/4112/4127/4595/9000		
		Xerox D125/D110/D95/D136		